

## Waterbars



*Tie-in the upslope end of the waterbar with the adjoining roadside bank ( circled ) and extend the waterbar across the travel path to a stable vegetated outlet area.*



*These waterbars are not effective since runoff will simply flow past them along the base of the bank because they are not tied-in.*